DUAL FX

	FX	DRY/WET	PARAM1	PARAM 2
● ● ●	MONO DELAY	DRY/WET	TIME	FEEDBACK
● ● ●	STEREO DELAY	DRY/WET	TIME	FEEDBACK
● ● ●	HI PASS DELAY	DRY/WET	TIME	HI PASS FILTER
● ● ●	BIG REVERB	DRY/WET	SIZE	TONE
● ● ●	SATURATED REVERB	DRY/WET	SIZE	TONE
● ● ●	STALKER REVERB	DRY/WET	TONE	FEEDBACK
● ● ●	RIPPER	DRIVE	CRUSH	DELAY TIME
● ● ●	DUAL PITCH SHIFTER	DRY/WET	SHIFT 1	SHIFT 2

DUAL FX

To assign CV input to control one of the parameters or dry/wet setting, push and hold the button for 2". The first effect indicator LED will start to flash, indicating that the CV is assigned to the first parameter. Push the button repeatedly to assign the CV input to the 2nd effect (the second LED flashes), to the dry/wet control (the third LED flashes) or leave it unassigned (all three LEDs flash). Push the SAVE button to confirm.